
Update manual for Capacitive touch panel

< Simple Description >

※ 'Mouse' is needed for this process.

<How to update Utility>

1. Reboot after deleting the utility 'SiW Touch Daemon' in Control panel.
2. Install the utility by executing '**SiWTouchDaemon_Installer_V1.1.7.0.exe**' file.


<How to update Firmware>

3. Push the '**F6**' button in keyboard after rebooting, executing Daemon utility, choosing the device to update by turns.
4. Proceed the update by clicking the '**FW Update**' button after recalling the firmware file by clicking '**File Open**' button.
Ex) **DNF_02_15.00_V1.6_B4.1_20180327.bin**
5. Wait until '**FW Update**' button is shown as 100%, and the right button is shown as '**FW Update**'.


※ Please refer to the detailed description part of this manual if this is not enough to understand.

< Detailed Description >

1. Reboot after deleting the utility 'SiW Touch Daemon' in Control panel.
2. Install the utility by executing 'SiWTouchDaemon_Installer_V1.1.7.0.exe' file as below.


 SiWTouchDaemon_Installer_V1.1.7.0

3. Execute 'SiW Touch Daemon' utility after finishing it and rebooting it.



< SiW Daemon Utility Interface >

4. Activate the buttons ②, ③, ④ by clicking 'F6' button in the above window.
5. Click the icon No. ① and No. ③ 'file open button by turns.
6. Click 'Open' button after finding the location which Firmware file is saved and proceed Firmware update by double-clicking the button 'FW Update'(No. ②) button



7. The update will be proceeded as the 'FW Update'(No. ②) button is changed as below. And it will be changed into 'FW Update' after it is proceeded as '100%'. And it will be finally finished as 'FW Update' icon is shown as below.

